




1884568

**O-Full/Queen Blaire Metal Headboard/Footboard
Parts List**


A.	Top Assembly	1 pc
B.	Middle Posts	2 pcs
C.	Bottom Assembly	1 pc
D.	Long Allen Head Bolts	4 pcs
E.	Short Allen Head Bolts	8 pcs
F.	Lock Washers	4 pcs
G.	Flat Washers	8 pcs
H.	Rubber Washers	4 pcs
I.	Nuts	4 pcs
J.	Spanner	1 pc
K.	Allen Head Wrench	1 pc
L.	Optional Allen Head Screwdriver Bit	1 pc

- * Please make sure that you have all the parts indicated above before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.
- * Take care not to overtighten bolts if using supplied Allen Head Screwdriver Bit.

Hardware Illustrations



D. Long Allen Head Bolt



E. Short Allen Head Bolt




F. Lock Washer



G. Flat Washer



H. Rubber Washer



I. Nut



1884568

O-Full/Queen Blaire Metal Headboard/Footboard Assembly Instructions

1. **Attach Bottom Assembly (C) to Brackets** Align the desired pre-drilled holes in the corner metal plates of Bottom Assembly (C) with the pre-drilled holes in the metal bracket ends. Bottom Assembly (C) should sit flush to the floor once it is attached. Insert Long Allen Head Bolts (D) with Lock Washers (F) and Flat Washers (G) through the metal bracket ends into the Rubber Washers (H) and the pre-drilled holes in the corner metal plates of Bottom Assembly (C). Secure with Flat Washers (G) and Nuts (I) using Spanner (J) and Allen Head Tool (K or L). **Note: Attach metal bracket ends to metal plates of Bottom Assembly (C) using inside holes for full bed or outside holes for queen bed.** See illustration.
2. **Attach Middle Posts (B) to Bottom Assembly (C)** Insert the posts of Bottom Assembly (C) into the Middle Posts (B). Make sure the pre-drilled holes in the Middle Posts (B) align with the pre-threaded holes in the posts of Bottom Assembly (C). Secure with Short Allen Head Bolts (E) using Allen Head Tool (K or L). See illustration.
3. **Attach Middle Posts (B) to Top Assembly (A)** Refer to step 1 to attach the Middle Posts (B) to Top Assembly (A). See illustration.

TO USE AS FOOTBOARD In order to use this item as a Footboard, eliminate steps #2 & #3 and attach the Bottom Assembly (C) directly to the Top Assembly (A). Secure with Short Allen Head Bolts (E) using Allen Head Tool (K or L).

NOTE: Headboard/Footboard can be attached to most standard metal bed frames (sold separately) that have a universal headboard bracket end as shown below.

